






NC Putty

Instruction

First clean the surface from grease, rust and dust. Add nitrocellulose thinner to reach the proper viscosity, and then apply.

	Apply with knife.
	10 min @ 20°C
	Drying Time: 60 min at 20°C
	P360-400
	Further Treatment: 2K or 1K Yashm primer and top coat
	36 months