

Wood NC Putty

Instruction

First clean the surface from grease, rust and dust. Add NC thinner to reach the proper viscosity, and then apply.

	Apply with knife.
	10 min / 20°C
	Drying Time: 10 min at 20°C
	P360-400
	Further Treatment: top coat
	36 months